





TIF
6
5
3
9
7
8
4
10
1
2


KEYPAD
6
MUTE
7
SENSITIVITY
5
RESET
SENSITIVITY
8
3
ON
OFF
BATTERY TEST
4


BATTERY INSTALLATION- Side View
BATTERY COVER
BATTERIES
Fig. 2


Green
Battery OK
Orange
Battery Low
Red
Replace Battery
CONSTANT POWER INDICATOR
Fig. 3


2.5V
2.6V
2.65V
2.7V
2.8V
2.9V
3.0V
Red
Orange
Green
BATTERY TEST DISPLAY
Fig. 4

